

## Fix for Vaccum Selonoid Transfer Switch

By Keil Thompson

Here is the solution if your vaccum selonoid fails:

Parts:

mac 35a-aaa-ddba-1ba valve 12v	2 each	total	\$ 34.00
arrow asp-1 exh muffler	2 each	total	3.20
28-4-2 parker fitting-qty	4 each	total	<u>0.44</u>
Grand Total for two complete valve assemblies			\$39.64

Installation:

The mac valves have three slots for the fittings.

I used teflon tape to get a good seal.

The exhaust fitting goes in the top numbered 3.

Install the parker fittings in the other two screw intakes>

The line from the manifold goes into the fitting that is marked 1 on the mac valve.

The line from the transfer goes into fitting marked 2.

Cut the old wire leads off and connect the mac valve leads connect the vaccum lines.

I formed a mounting bracket out of aluminum.

To find mac valve dealer go to [www.macvalves.com](http://www.macvalves.com)

I got mine here in ga. from tsi solutions 770-879-3500 but i think that they only sell in georgia