



Technical Service Information Bulletin

February 28, 1997

Title:

PUBLICATION CORRECTION INFORMATION

Models:

'95 - '97 LS 400, '97 GS 300, '97 ES 300,
'97 LX 450

PG001-97

PRODUCT GENERAL INFORMATION

Introduction Corrections have been made in the repair manuals listed below. A brief Description of each correction is provided. For further details, refer to the appropriate Correction Page (attached to this TSIB for Dealer Area Office distribution). These pages should be attached in the corresponding publication.

NOTE:

When ordering a technical publication (i.e. Repair Manual, Electrical Wiring Diagram) From the MDC, any Correction Page(s) associated with that particular Publication, will be automatically included with your order.

Additional Correction Pages are available through the Dealer Support Material Network (MDC NPM System) via the corresponding part numbers from the following table:

**Parts
Information**

PUBLICATION	NUMBER	PAGE(S)	DESCRIPTION	PART NUMBER
'95 LS 400 Repair Manual	RM405U1	AT-74	AUTOMATIC TRANSMISSION- TROUBLESHOOTING. INSPECTION PROCEDURE- Step 1 was completely revised. Step 2, P 1. Remove transmission. was revised to 1. Remove the oil pan.	00245-RM405-6012
'96 LS 400 Repair Manual	RM439U1	AT-51	AUTOMATIC TRANSMISSION- TROUBLESHOOTING. INSPECTION PROCEDURE- Step 1 was completely revised. Step 2, P 1. Remove transmission. was revised to 1. Remove the oil pan.	00245-RM439-6012
'97 LS 400 Repair Manual	RM514U1	BR-18	BRAKE - FRONT BRAKE. 5. MEASURE DISC RUNOUT - (B) Text revised to include . . . <i>grind it on a "on-car" brake lathe.</i>	00245-RM514-6041
	RM514U	BR-24	BRAKE - FRONT BRAKE (Disc Brake) 4. MEASURE DISC RUNOUT - Text re- vised to include . . . <i>grind it on a "on-car" brake lathe.</i>	
'97 GS 300 Repair Manual	RM512U	BR-17	BRAKE - FRONT BRAKE. 3. MEASURE DISC RUNOUT - Text revised to include . . . <i>grind it on a "on-car" brake lathe.</i>	00245-RM512-6041



**Parts
Information**
(Continued)

PUBLICATION	NUMBER	PAGE(S)	DESCRIPTION	PART NUMBER
'97 GS 300 Repair Manual	RM512U	BR-20	BRAKE - REAR BRAKE (Disc Brake). REAR BRAKE COMPONENTS INSPECTION AND REPAIR. <u>3. MEASURE DISC RUNOUT</u> - Text revised to include . . . <i>grind it on a "on-car" brake lathe.</i>	00245-RM512-6041
'97 ES 300 Repair Manual	RM511U	DI-248	BRAKE - ANTI-LOCK BRAKE SYSTEM. <u>DTC - REAR SPEED ROTOR FAULTY</u> - Revised to 33, 34.	00245-RM511-6048
'97 LX 450 Repair Manual	RM515U	BR-10	BRAKE - BRAKE BOOSTER ASSEMBLY. <u>BRAKE BOOSTER ASSEMBLY</u> - Entire page has been revised from Brake Master Cylinder <i>Removal</i> and <i>Disassembly</i> to Brake Booster Assembly <i>Operational Test</i> and <i>Components</i> .	00245-RM515-6055